



VINYL PLANK TRIM STAIR NOSING

INSTALLATION INSTRUCTIONS

Check to make sure the vinyl plank flooring thickness properly fits into your selected Vinyl Plank Stair Nosing profile.

Floor Prep: Make sure the steps (substrate) where the Vinyl Plank Stair Nosings are being placed are clean and dry.

MEASURE & CUT



- 1 Measure and cut Vinyl Plank Stair Nosing to needed length using either a miter saw, chop saw or hacksaw with the highest number of teeth per inch.

Once the Stair Nosing is cut, make sure to remove any burrs or sharp edges off the cut ends.

APPLY ADHESIVE TO SUBSTRATE & TRIM



- 2 Determine exact Vinyl Plank Stair Nosing location and mark its outline on the steps (substrate).

Apply a thin layer of construction-grade or urethane-based adhesive to the back of the Stair Nosing and to the substrate area where the Stair Nosing will be placed.

PLACE & SECURE



- 3 Place Vinyl Plank Stair Nosing into position on the substrate and press down firmly for a strong adhesive bond. **MAKE SURE TO CLEAN OFF ANY EXCESS ADHESIVE FROM THE VISIBLE SURFACE OF THE STAIR NOSING AND VINYL PLANKS.**

Insert the vinyl plank flooring halfway into the opening of the Stair Nosing to allow for expansion.

For an even more secure installation, drill pin holes into the horizontal surface (foot) of the Stair Nosing profile and substrate, then hammer in flat head nails. Make sure nails end up flush with the profile.

Ensure the installation is free of foot traffic for 24 hours.

Install Vinyl Plank Flooring according to manufacturer's installation instructions.