

## J-BEAD



### Step 1:

Make sure the surface of the drywall is clean and smooth. Avoid using the tapered edge of the drywall board for this application. Measure and cut the J-Bead to length. Dry fit the J-Bead to ensure the optimum fit.

### Step 2:

Position the short flange of the J-Bead so that it is facing the room's interior. Slip the J-Bead over the edge of the drywall until both edges meet. No fasteners are required to attach the J-Bead to the drywall.

### Step 3:

Install the drywall equipped with the J-Bead using screws as normal.