

FAST & SIMPLE INSTALLATION

- 1 Secure E4586 Handrail Support plate to wall using appropriate fastener.
- 2 Using E600/D1 Drilling Guide, align, drill & install EINSM6X12 Threaded Insert into Wood Railing.
- 3 Assemble & attach E4586 arm components to Wood Railing.
- 4 Slide onto wall plate and secure with set screw.



IAM DESIGN
INNOVATION ARCHITECTURAL METAL
Italian-Designed Handrail Accent