



GRONOMICS® “TOOL FREE ASSEMBLY”

34” x 34” RAISED GARDEN BED - TWO TIER Parts Check List and Assembly Instructions

STEP I

- A) Unpack all of the parts and organize them in ‘like’ stacks. Please read the instructions in its entirety before beginning assembly.

You should have:

Model #RGB2T 34-34

QUANTITY	PART DESCRIPTION	PART #
4	4” x 4” x 13” Corner Post	1300
Parts for the two Sides		
8	31” x 5½” x 1” Side Rail (One w/Logo)	3101, 3101L
Packaged & Inspected by:_____ Date_____		

NOTE: If you need assistance with parts or have assembly questions, please contact Customer Service either via email at info@cwpmulch.com or phone at 763-753-7374.



GRONOMICS® “TOOL FREE ASSEMBLY”

STEP II

- A) Start with two 4” x 4” x 13” corner posts, place the posts upside down.
- B) Slide one 31” x 5½” x 1” side rail between the two posts. (see figure 1)
- C) Repeat the same process with the other two 4” x 4” x 13” corner posts and the other 31” x 5½” x 1” side rail. Make sure the 31” x 5½” x 1” side rail w/logo is placed upside down in this step.

(Figure 1)



(Figure 2)



STEP III

- A) Connect the two corner posts by sliding a 31” x 5½” x 1” side rail into each post. (see figure 2)
- B) Slide the remaining four 31” x 5½” x 1” side rails into the posts.

(Figure3)



STEP IV

- A) Turn right side up.

Note: Ground preparation is optional; level area to be planted before placing bed and filling with soil.

Recommended Finish: A natural oil non film-forming finish designed for Cedar. If Cedar is not finished checking may occur and will naturally turn a weathered gray color.

1-Year Warranty: All Gronomics® Products are warranted against all manufacturing defects of material or craftsmanship for a period of ONE full year from date of purchase. Warranty does not cover cracking, damage caused by negligence, alterations or abuse in any way.