

PAVERS | CAMDEN COBBLE®

## Camden Cobble®

### INSTALLATION



Excavate the installation area to approximately 6 in. (152mm) larger on all sides than the actual finished size.



Lay patio stones in the desired pattern. If the desired pattern requires cutting, the patio stones can be cut with a wet saw.



Install patio base to a compacted finished thickness of 4 in. (102mm) for patios and walkways.



Install paver restraint edging and spikes around the entire project, according to the manufacturer's instruction.



Lay a 1 in. outside diameter pipe on base. Spread 1 in. of sand over compacted base. Level the sand by dragging a 2 in. x 4 in. (51mm x 102mm) board over pipe.



Spread polymeric sand on the installation and sweep into joints, according to manufacturer's instructions. Sweep off any loose sand from project surface.



Keystone Retaining Wall Systems LLC • A Contech Company  
4444 West 78th Street • Minneapolis, MN 55435  
(952) 897-1040 • [www.keystonewalls.com](http://www.keystonewalls.com)

©2017 Keystone Retaining Wall Systems LLC

