

FAST & SIMPLE INSTALLATION

- 1 Drill pilot holes & attach E600/T Accent Connectors to ends of Wood Railing (use the E600/D Accent Connector Guide for proper alignment).
- 2 Push-fit the E600 Round 90° Elbow onto the Accent Connectors.

