B2841 ADIRONDACK 1-LT. SCONCE INSTALLATION INSTRUCTIONS



DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.



This fixture is designed to be mounted on a correctly installed standard round or octagon box or a through wiring box
with a plaster frame. The box must be securely mounted to the structure of the building. The crossbar and hardware supplied
should be used. directly mounting the fixture to the outlet box may make it impossible to correctly align the fixture.

FIXTURE PREPARATION

1. Remove the fixture, shade and parts bag(s) from the carton.

NOTICE: Before discarding the carton, double check to make certain that all parts are found.

FIXTURE INSTALLATION

- 1. Attach the mounting ring to the outlet box. (the green screw should face out).
- 2. Fasten the ground wire to the green or bare copper wire in the outlet box or the green screw on the mounting ring.

Never fasten the ground wire to the black or "hot" wire! Failure to follow this instruction could result in serious injury or death!

3. Fasten the white fixture lead to the white wire in the outlet box. Fasten the wires together with an approved fastener (wire nut). Starting about 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener. Lamp-WARNING Make sure that there is no exposed wire or strands that could cause a dangerous short circuit! SHADE Electrical tape Approved fastener (wire nut) 4. Connect the black fixture lead to the black wire in the outlet box. Fasten the joined wires as in step 3.! Back plate 5. Using the two (2) screws and fasten the fixture to the outlet box. 6. Install the lamps (lighting bulbs). NOTE: This fixture is rated for candelabra based, 60 watt type B, BA, C, or CA lamps Green screw 7. Put the shade into place. Outlet box-WARNING DO NOT EXCEED RECOMMENDED WATTAGE! 8. Restore power to circuit at breaker or fuse box. Mounting ring

Screw