## **INSTALLATION INSTRUCTIONS**

# **Installation Manual**



<u>Series</u>

own above. Any change in material, on Committee, or any evidence of ause for revocation of this listing. I ADPAD Research and Texang, Inc.

ine at pld.larmo.ord

Void After: October 2017

File No. 4955





## **INSTALLATION STEPS**

This product has been inspected and

condition. Please do not disassemble

debugged by the factory to the best

and assemble it yourself.

No disassenthling



### Instruction of use

1. Turn on the faucet handle.

2. Rotary diversion valve, and follow the icons above switch to Rain shower head, Hand shower and faucet outlet.

3. Rotate the faucet handle left and right to adjust the temperature of hot and cold water.

### **CLEANING CARE**

In order to keep the appearance of faucet clean, bright and good performance, please take care of the faucet as follows;

- 1. Rinse with water only and dry with soff cotton cloth;
- 2.Use mild liquid and colorless glass cleaner to remove surface dirt and scale film, or use polish without abrasive effect;
- 3.Do not use abrasive deterfgent, polish, emery cloth, paper towel or scraper, etc.;

4.Do not use acid cleaner, or cleaner and soap with insoluble gran etc.;

5. In the process of use, mud my accumulate in the bubbler and make the water flow show, The bubbler can be unscrewed, rinsed with water, and then installed back in place.

Please feel free to contact us if you have any questions. We will help to solve the issue together with you. OUR EMAIL: services@rbrohant.com

Before installing the faucet, please be sure to remove sundries and sludge from the water pipe to prevent sundries from blocking the faucet.

#### ▶ installation steps

1. Drain the sewage from the hot and cold water pipes first.

2. Install the faucet ① in place, connect ② and ③, and then insert it into ① to check whether it is in place. Place ③ close to the wall, determine the fixed point, make a mark, and then drill the hole.

3. Insert ④ into ②, then fix ②, ③, ④ on the wall at the same time, and check whether the installation is stable.
4. Finally, fix ⑥ in an appropriate position, then connect ⑧ to ①, and then connect ⑦ to ⑧. Then connect ⑤ to ④. Note that the rubber pads of all connecting parts must be installed in place.

5. Finally, test the water to check whether the connecting parts are leaking. So far, the entire shower is installed.

