## 7156D45FG ASSEMBLY INSTRUCTIONS

## Disclaimer:

Thank you for your purchase. Please read carefully and keep these instructions, as you may need them later.

Beware of potential electrical shock! Before installing the fixture or removing any other light already present, please turn off the main power at the circuit breaker.

If your product contains glass items, please handle with care, as glass is fragile and can lead to injuries if handled incorrectly.

Please keep in mind that the warnings and instructions present in this document are not meant to cover and prevent all possibilities and situations that could lead to injury or damage. It is the responsibility of the end-user to exercise caution and common sense when handling and installing the product.

All electrical connections must be made by qualified personnel in accordance with the National Electrical Code.

Please refer to the table below for electrical connections:

Fixture wire markings:	AC power equivalent:
"L" Live wire (Black or Brown)	"L" Live wire (Black)
"N" Neutral wire (White or Blue)	"N" Neutral wire (White)
"≟" Ground wire (Green or Bare)	"  —  "  Ground wire (Green or Bare)

For installation, please refer to the written instructions at the back.

Need to contact us?
Please send an email at:
service@aloadecor.com

Need more information?
Please visit our website:

www.aloadecor.com



## Installation instructions:

**Step 1.**Install the chains between lamp body's ring(F) and canopy(C) by activity buckle(E), the chain is adjustable. And pass the main wire through the chain.

**Step 2.**Use the two screws(B) secure mounting bracket(A) to the junction box.

**Step 3.**Twist the brass ground wire "E/⊕" with the M4 green threaded screw on the mounting bracket and lock it to the GND position .Then twist the two ground wires together (one is the brass ground wire "E/⊕", the other is the ground wire from the junction box ,and tighten it by the terminal nut.

**Step 4.**Black wire from junction box attaches to "L" wire for the fixture by terminal nut; white wire attaches to "N" wire by terminal nut.

**Step 5.**Use the screw nut(D) secure canopy(C) to the mounting bracket(A).

**Step 6.** Unscrew the final(P),cap(M),rod(J) as shown drawing 1.

**Step 7.**Install the bulbs( not included).

**Step 8.**Install the rod(J) on the centre nut(H) and lock the cap(M) by final(P).

