





ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. Unravel the supply power and ground wires and pass them through the center holes of center rod (J), top frame (I), rods (H), rod (G), loop (F) and canopy (D).
4. Thread the socket assembly(A), the center rod (J), and the top frame(I) together as shown. Hand tighten until snug.
5. Place the bottom frame(C) onto the protruding nipple at the bottom of the center frame (K), securing with finials (B). Place the top frame (I) onto the protruding nipple at the top of the center frame (K), securing with finials (B), as shown in the diagram.
6. With beveled edges of the glass (M) outward, attach the glass (M) to the frame. Insert the pin on the glass (M) slantingly into the small hole of the bottom frame (C) and bend it. Repeat process for remaining glass (M), (N) and (L). Place the glass (M), (N) and (L) into the slot. Install glass from bottom to top. The center frame (K) requires two layers of glass (N) or (L) to be installed, and the lower layer of glass (N) or (L) should be completely installed before installing the upper layer of glass (N) or (L).
7. Thread the rods (H) into the coupling at top of center frame (K). Repeat process for remaining rod (G). Hand tighten until snug. Install the loop (F) into the top of rod (G).
8. Use the carabiner (E) to connect the loop (F) to the loop on the canopy (D) and twist the locking mechanism to secure.
9. Refer to the additional installation instructions included with the product for wiring and installation.
10. Install proper bulbs (not included) into each socket referring to the markings and/or labels on the fixture for maximum wattage.
11. Restore power to the installation point and retain this sheet for future reference.