

Align chain guard position, drill pilot holes,
then secure with 6 screws included.

