

This bathroom fixture has been carefully engineered to provide a long, trouble-free service life under normal usage. It has been factory-tested and is ready for installation. We suggest this fixture be installed by a qualified licensed plumber so the warranty will remain in affect (refer to the “General Information” section for warranty information). We also strongly recommend tub & hardware be on site prior to rough in.

- Shut off the water supply before installation.
- Use Teflon tape on all threaded connections.

1. Slide floor escutcheon onto the straight tube from the bottom. Open end of escutcheon facing the floor.
2. Attach the 3 prong seat to the straight tube.
3. Thread the hot and cold flexible supply tubes through both the 3 prong seat and the straight tube from the bottom. Tighten the flex tubes to the faucet body.
4. Screw faucet body to the straight tube.
5. Insert expansion screws into floor using 3 prong seat as template.
6. Attach the flexible supply tubes to your house water supply lines.
7. Attach the 3 prong seat to the floor over your house water supply using the included screws/bolts.
8. Attach the hand shower to the hose and connect to the faucet body.
9. Test the faucet spout and hand shower for water flow, function and leaks.