PREPARATION

Before beginning installation of product, make sure all parts are present. Compare parts with package contents list diagram above. If any part is missing or damaged, do not attempt to install the product.

Estimated Assembly Time: 10 minutes

Tools Required for Assembly (not included): Drill with 3/32 in. and 5/16 in. drill bits, Phillips screwdriver.

Helpful Tools (not included): Level, Pencil

TOOLS REQUIRED:



CARE AND MAINTENANCE

On an annual basis, it is recommended to double check all connections and re-tighten all screws and anchors. Clean with a lightly damp cloth or towel using water only to protect the durability of the finish on hooks and the rail.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Rail not level.	Original measurements are inaccurate.	Re-install starting with level marks.



ITEM #670161/6534499 MODEL #49551

4-HOOK RAIL

Español p. 4

STYLE SELECTIONS and logo design are trademarks or registered trademarks of LF, LLC. All rights reserved.

ATTACH YOUR RECEIPT HERE



Thank you for purchasing this STYLE SELECTIONS product. Questions, problems or missing parts? Before returning, contact us on: 877-888-8225, 8 a.m.-8 p.m., EST, Monday - Sunday or ascs@lowes.com.

Printed in Vietnam

SG241291

4

TABLE OF CONTENTS

Package Contents	. 2
Hardware Contents	2
Safety Information	. 2
Assembly or Installation Instructions	. 3
Preparation	. 4
Care and Maintenance	. 4
Troubleshooting	4

PACKAGE CONTENTS



HARDWARE CONTENTS



Gty. Z

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

The maximum load for this decorative rail, regardless of mounting application, is 8.8 lbs.

When drilling into the wall, avoid any electrical wiring or plumbing that may be located behind the wall. Damaged electrical wiring can cause electrical shock and/or fire.

ASSEMBLY INSTRUCTIONS

Note: Product intended for solid wood/wood stud installation only.

 Temporarily place rail (A) in desired location and mark mounting hole locations. Remove rail (A) and drill 3/32 in. pilot holes at marks.



 Secure rail (A) to mounting surface with screws (AA). Do not overtighten.

Hardware Used



Screw Annument x 2

