

BALUSTERS

INSTALLATION GUIDE

Before beginning the project, please check local building code requirements.

STEP 1 - Measuring

Measure the **distance between the top handrail and bottom base rail**.

STEP 2 - Determine baluster spacing

Standard building codes require **maximum 4-inch spacing** between balusters.

STEP 3 - Cutting the balusters

Depending on style of balusters, cut to fit into space between top handrail and bottom base rail.

STEP 4 - Attach balusters to railing

- Drill pilot hole into railing & balusters.
- Use a level to ensure balusters are vertical.
- Attach baluster to railing with baluster screw.

STEP 5 - Finishing

- Fill nail holes with wood filler.
- Sand smooth.
- Apply stain, paint, or clear finish.

THE DIAGRAMS AND INSTRUCTIONS IN THIS BROCHURE ARE FOR ILLUSTRATION PURPOSES ONLY AND ARE NOT MEANT TO REPLACE A LICENSED PROFESSIONAL. ANY CONSTRUCTION OR USE OF THE PRODUCT MUST BE IN ACCORDANCE WITH ALL LOCAL ZONING AND/OR BUILDING CODES. THE CONSUMER ASSUMES ALL RISKS AND LIABILITY ASSOCIATED WITH THE CONSTRUCTION OR USE OF THIS PRODUCT. THE CONSUMER OR CONTRACTOR SHOULD TAKE ALL NECESSARY STEPS TO ENSURE THE SAFETY OF EVERYONE INVOLVED IN THE PROJECT, INCLUDING, BUT NOT LIMITED TO, WEARING THE APPROPRIATE SAFETY EQUIPMENT. EXCEPT AS CONTAINED IN THE WRITTEN LIMITED WARRANTY, THE WARRANTOR DOES NOT PROVIDE ANY OTHER WARRANTY, EITHER EXPRESS OR IMPLIED, AND SHALL NOT BE LIABLE FOR ANY DAMAGES, INCLUDING CONSEQUENTIAL DAMAGES.