

1. Do not walk on the door.
2. Avoid leaving unfinished doors in direct sunlight. Doors should not be subject to abnormal heat, dryness or humidity.
3. Keep doors clean.
4. When moving doors, never drag doors across one another. Use clean, gloved hands and always have at least two people to lift and carry the doors to distribute pressure and prevent injury. Keep the original packaging intact to protect the doors from dirt, moisture, and physical abuse.
5. Store door slabs flat on a level surface in a dry, well-ventilated interior space. Place at least three full-width bearers (like 2x4s) evenly spaced under the doors to lift them off the floor and prevent moisture damage and condensation. Ensure that the supports extend wider than the door itself to distribute weight evenly and avoid bowing.
6. Store pre-hung units in a vertical position, in the original packaging, leaving enough room for air to circulate.
7. Avoid leaning doors at an angle or placing them on unsteady ground. Uneven pressure can lead to warping.
8. Doors should be conditioned to the average prevailing relative humidity of the locality before hanging. This generally takes 48 to 72 hours.
9. Doors should be delivered to the building site only after the concrete, plaster, stucco, drywall work and paint are completely dry.