


# Outdoor Cordless Roll-Up Shade


## HARDWARE COMPONENTS/ HERRAJES

Quantities by Size: Anchura (cm)	48 in 121.9cm	72 in 182.9cm	96 in 243.8 cm
Eye Hooks	3	4	5
Straps with Clip	3	4	5




### 1. HOW TO INSTALL

Before installing make sure shade is fully rolled up and secured.




#### INSIDE MOUNT

Montaje interior




#### OUTSIDE MOUNT

Montaje exterior




### 2. POSITION SHADE

Make sure your marks for the screw holes are level or at least the same distance from the top of the window. For best accuracy, measure the distance with a tape measure.



### 3. INSTALL EYE HOOKS

Drill 1/16" pilot holes at the x marks, insert eye hooks and tighten. If necessary, use pliers to tighten.



### 4. HANG THE SHADE


To hang the shade, simply hook the mounting eyelets over the eye hooks.

### 1. CÓMO INSTALAR

Antes de la instalación, asegúrese de que la persiana esté completamente enrollada y asegurada.

#### INSIDE MOUNT

Montaje interior



#### OUTSIDE MOUNT

Montaje exterior



### 2. POSICIÓN DE PERSIANA

Asegúrese de que sus marcas para los orificios para tornillos estén niveladas o al menos a la misma distancia de la parte superior de la ventana. Para una mejor precisión, mida la distancia con una cinta métrica.

### 3. INSTALAR LOS GANCHOS DE OJO

Perfore orificios de 1/16 "en las marcas x, inserte los ganchos de ojo y apriételos, si es necesario, use alicates para apretarlos.

### 4. CUELQUE LA PERSIANA

Para colgar la persiana, simplemente enganche los ojales de montaje sobre los ganchos de ojo.