

Instructions

Tools Required: Plumber's Putty

1. Remove Shank Nut (A) and Putty Cup (B) from Faucet Hole Cover (C).
2. Roll Plumber's Putty into a rope bead about $\frac{3}{8}$ " in diameter. Place under rim of Faucet Hole Cover (C) with ends overlapping. Place a similar rope bead on top of Putty Cup (B) with ends overlapping.
3. Insert Faucet Hole Cover Shank (D) into hole in deck of sink.
4. Slide Putty Cup (B) onto Shank (D). Screw Shank Nut (A) onto Shank (D) hand tight. **DO NOT OVERTIGHTEN.**

