



The Window Frame Experts!

Product Directions

Shine-It Kits

PRODUCT APPLICATIONS

1. For use on; vinyl, acrylic, aluminum or to refurnish wood.
2. Clean area of any and all dirt or grime.
3. *Recommended: Sand wet with clean water to increase lifespan of sanding pads and prevent grit clogging.*
4. Use heaviest grit sanding pad needed depending on the severity of damage on the effected area.
5. Once damage starts to fade, change to progressively lighter grits. For best results, do not skip grit levels.
6. When scratches or gouges are removed, switch to polishing pads (#7 and #9). Polish until desired shine is achieved.
7. Wipe clean with water and rag or additional VinylDoc cleaning products.
8. For product tutorials with regards to specific repair situations, please visit vinyldoc.com.

SANDING PAD GRITS

- Pad 1 (*Rough Sanding*): FRONT - 120grit / BACK - 180grit
Pad 3 (*Medium Sanding*): FRONT - 240grit / BACK - 320grit
Pad 5 (*Smooth Sanding*): FRONT - 400grit / BACK - 600grit
Pad 7 (*Satin Polishing*): FRONT - 1200grit / BACK - 2400grit
Pad 9 (*Shine Polishing*): FRONT - 4000grit / BACK - 8000grit

