

Align handle position, drill pilot holes, then secure handle with 4 screws included.

