


Y52EDDC5010R-CH
Y52EDDC5009R-CH


CUCULIDAE

CEILING FAN



52-INCH DEROCATE CEILING FAN USE AND CARE GUIDE

Installation of the hanging bracket




For concrete ceiling, use the percussion bit with diameter 8mm to drill holes according to the length of expansion screws. Then use the attached expansion screws to fix the hanging bracket onto the ceiling (selection is made according to actual requirements of the customers).

STEP 1 A-CONCRETE CEILING

SWITCH OFF THE ELECTRICAL MAINS AT THE CIRCUIT BREAKER FUSE BOX.

- 1) Use the Mounting Bracket as a guide, mark the spots where the 4 Expansion Bolts will be drilled.
- 2) Remove the Mounting Bracket, drill 2 holes and insert 2 Expansion Bolts into the concrete ceiling, install the mounting bracket and secure with Flat Washers, Spring Washers and Nuts.

IMPORTANT : SCREWS & NUTS MUST BE TIGHTENED TILL SNUG




For wooden ceiling, use wood screw to drill on the wooden beam or the "junction box" to fix the hanging bracket(selection is made according to actual requirements of the customers)

STEP 2 A-WOODEN CEILING


SWITCH OFF THE ELECTRICAL MAINS AT THE CIRCUIT BREAKER FUSE BOX.

- 1) Use the Mounting Bracket as a guide, mark the spots where the 4 Self Tapping Screws will be drilled.
- 2) Remove the Mounting Bracket, drill 4 holes for 3MM diameter, install the mounting bracket onto wooden ceiling with the 4 Self Tapping Screws & Washers

Pre-Installation




Parts Kit




NOTE

Hardware not shown to actual size.

Install downrod assembly




Hang the fan






- ☐ Carefully feed the motor wires up through the downrod
- ☐ Align the holes and replace hanger pin and locking pin.
- ☐ Tighten the two collar setscrews.
- ☐ Slip coupling cover, canopy cover and canopy onto the downrod.

Install canopy




- ☐ Ensure the loosened screws are inserted into the key holes on the mounting bracket.
- ☐ Carefully raise the canopy up to the mounting bracket. Rotate the canopy clockwise.
- ☐ Secure the canopy by replacing the screws previously removed and tightening the screw previously loosened
- ☐ Place the canopy cover (if applicable) and rotate the canopy cover clockwise until it locks into position.

Fastening the blade arms to the motor





- ☐ Fasten the arm to the fan-motor assembly by inserting the alignment post into the slot on the bottom of the motor and tightening the pre-installed arm screws.
- ☐ Repeat this step for the remaining blade assemblies.



Finish


Making the electrical connections



Assembly - Hanging the Fan(continued)


Preparing for mounting

Install remote control





- 1) Carefully push the canopy to the bottom of the mounting bracket, make two sliding holes aligned to the two prominent screws on the mounting bracket, and then turn clockwise until light.
- 2) Push the canopy ring to the bottom of the canopy, slide the inner holes aligned to the two prominent screws on the mounting bracket again, and turn the canopy ring clockwise until light.

Preparing for mounting





- 1) Remove the mounting bracket from the canopy by loosening the two canopy screws located in the L shaped slots
- 2) Remove and save the two canopy screws in the round holes. This will enable you to remove the mounting bracket

Assembly-Attaching the Lights



- ☐ Screw the lamp tray to the motor assembly.



- ☐ Screw the LED light source to the lamp plate
- ☐ Insert the "white" line in the switching box of the motor into the "white" line of the light and tie insulated rubber tape.
- ☐ Insert the "blue" line in the switching box of the motor into the "blue" line of the light and tie insulated rubber tape.
- ☐ Install the lampshade on the lamp plate by rotating it counterclockwise.

Use of remote control

