# How To Measure Inside-Mount 2-in Cordless Room Darkening Faux Wood Horizontal Blinds

Things to consider before purchasing: Check for obstacles and window sash depth.

Tool Needed: Note Paper / Pencil / Measuring Tape.

If your window has an obstacle check if there's enough depth of 2-3/4". If less than 2-3/4", proceed with Outside Mount Measurement.

Let's start Inside Mount Measurement.

#### Step 1: Measure For the Width

Measure the width inside the window frame at – top, middle, and bottom, to allow for variances in construction.

- Measure to the nearest 1/8 of an inch.
- Use the smallest measurement as the window width to make sure that the blinds clear the sides of the window frame.

### Step 2: Measure For the Height

Measure the height inside the window frame at - left (h1), middle (h2), and right (h3), to allow for variance construction.

- Round the measurements down to the nearest 1/8 of an inch.
- Use the largest measurement as the window width so the blinds cover the entire opening.

### Step 3: Final Measurements

Measure the window diagonally.

- If the two diagonal dimensions differ significantly, it may be necessary to order outside-mounted blinds for optimal light control and privacy.
- Measure the window area exactly.

# Step 4: Place Order

- Round measurement DOWN to the closet available size for width.
- If your exact window height is not available, round UP the next larger height.

