

DESIGNED FOR LIFE

## **Assembly Instructions**



Bar Table

Model NO: HOGA-NY281 HOGA-NY282 HOGA-HL0238



# Contact Us We're here to help you.



Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.

## Warm Tips

- 1. Carefully read these instructions and keep them for future reference.
- 2. Check the parts list and confirm everything's there before starting assembly.
- 3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
- 4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.

### How to Get the Assembly Video



Note: If you can't find the assembly video, please contact us.



We recommend using hand tools for assembly.

If an electric screwdriver is used, reduce power and torque to avoid damage to the product.



## Install the Anti-Tip Straps

Using the anti-tip straps can reduce the risk of tipping over, but can not eliminate it.





## Please split component into "I" and "J" before assembling the slide and then proceed to the next step of assembly

## Step 1

Pull apart component to each side, and then gently push up the lever of component "J"







#### **Caution**

ГТ

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.

## **Parts List**

 $\Delta$ 



## **Parts List**

 $\Delta$ 

A	В	С	D	E	F
			OLIMAN	A CONTRACTOR	
Ø6x35mm	Ø15x12mm	Ø8x30mm	Ø7x38mm	Ø3.5x14mm	M4x22mm
26pcs+1pc	26pcs+1pc	10pcs+1pc	20pcs+1pc	52pcs+2pcs	8pcs+1pc

G	Н		J	K	L
4mm		290mm	290mm	0	0
1рс	2pcs	8pcs	8pcs	4pcs	8pcs



## Installation of Cams and Pins

Read each step carefully before starting. Each step of instruction should be performed in the correct order. If these steps are not followed in sequence, assembly difficulties may occur.



Screw the pin into the hole. Set the cams correctly by aligning the head of the cams with the lock pins. Lock the cam by turning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.



#### Tribesigns

















K	
0	
4pcs	









#### Tribosigns





X4



















# Thank you for your support!



