

FENCE WEAVE



DIAGRAM 1



DIAGRAM 2



DIAGRAM 3

INSTRUCTIONS FOR A QUICK & EASY INSTALLATION

To determine how many rolls are needed, just follow this easy formula:

Height of fence x Length of fence

÷ 40 = Number of rolls

(example: 4' x 50' ÷ 40 = 5 rolls)

1. Pull out end of FENCE WEAVE® and measure against (diagonal) fence. Cut strips 3 inches longer to allow for 1½" overlap on each end. (See Diagram 1)
2. Starting at either top or bottom of fence, weave FENCE WEAVE® over one and under the next wire rung. (See Diagram 2)
3. Fold over the 1½" overlap and push fastener (included) through FENCE WEAVE® and spread prongs. (See Diagram 2)
4. Pull on other end to take out most of the slack (caution: leave ½" slack for shrinking) and insert fastener.

Repeat steps 1-5 until fence or desired section of fence is covered. By combining 2 or more colors an Infinite number of designs are possible. (See Diagram 3)



PEXCO LLC

Phone: (978) 249-5343 • Toll Free: (800) 755-SLAT (7528)

Website: www.pexco.com/fence

Made in U.S.A.