

STRAIT-FLEX® TILE-TAPE



INSTALLATION

- Cut Tile-Tape to desired length.
- Fold in half at center crease for inside or outside corners.
- For inside corners, print-side faces out.
- For outside corners, print-side faces wall.
- Using a 5" or 6" taping knife, apply a liberal coat of tile-setting compound such as latex-fortified mortar or Type 1 organic adhesive to flat joints or inside corners. Press Tile-Tape into wet compound.
- Adjust if necessary to create a straight line and wipe down with taping knife.
- Apply tile-setting compound with notched trowel and install tile or marble.