



For 1-3/8" to 2-3/8" Thick Doors
Para puertas de 3.5 cm a 6 cm de espesor
Pour les portes d'une épaisseur de 3.5 cm à 6 cm

Installation instructions:

Install in desired location as illustrated. Drill 3/32" holes for the 3/4" strike screws and the longer lock mounting screws. When drilling cylinder hole, drill small pilot hole through the door and then drill 1-1/4" hole half way through door from each side to reduce splintering.

Instructions d'installation:

Installez la serrure à l'endroit désiré, tel qu'illustré. Percez des orifices de 3/32" pour les vis de 19 mm de la gâche et pour les vis plus longues servant au montage de la serrure. Lors du perçage de l'orifice pour le cylindre, percez un petit orifice pilote et par la suite, percez un orifice de 1-1/4" à moitié chemin à travers chaque côté de la porte, pour réduire de fendillement du bois.

Instrucciones para la instalación:

Coloque la cerradura en el lugar deseado, como se muestra. Taladre orificios de 3/32" para los tornillos de 19 mm utilizados sobre la placa para el marco y para los tornillos más largos, utilizados para el montaje de la cerradura. Para taladrar el orificio del cilindro, haga un pequeño orificio piloto y después taladre un orificio de 1-1/4" en la mitad, a través de cada uno de los lados de la puerta, para reducir las resquebrajaduras de la madera.

