



PRIOR TO INSTALLATION

- Allow your countertop to acclimate for 72 hours prior to installation. Sand and apply a finish immediately after acclimating.
- The wood may bow slightly upward at the edges if it is stored for a long period of time. To return the surface to its original condition, turn it over and lay it on its face until it's reformed to its original shape.
- Check the color and finish of your surface before installation. You cannot return or exchange the product once it has been altered or installed.
- Keep in mind that wood is a natural material, so each surface can vary slightly in color, tone, and characteristics. This adds to its beauty.
- Lightly sand all surfaces of your CenterPointe countertop with 120 grit sandpaper, in the direction of the wood grain, prior to applying finish.
- All surfaces of the CenterPointe countertop must be finished. This includes top, bottom, edges and ends. Typical finish options include oil, wax, sealant, stain, urethanes, and acrylic.


DURING INSTALLATION

- Reapply finish, according to the manufacturer's instructions, to any areas that have been cut during the installation process.

Always use protective equipment when cutting and installing your CenterPointe countertop.

FOR DAILY USE

- Clean the countertop in accordance with the finish manufacturer's instructions.
- Do not use harsh or abrasive cleansers or chemicals to clean the countertop.
- Do not place hot items directly on the surface.
- Avoid cutting directly on the wood, as this could damage the surface.

 **WARNING:** This product can expose you to chemicals including respirable wood dust which is known in the State of California to cause cancer. For more information go to: www.P65Warnings.ca.gov/wood

*Warranty is void if the surface is not sanded and sealed or finished.