

**Step 5:**

Adhere the hook & loop tape portion of the screen to the top of the doorframe. **The screen should be slightly higher in the top center.** This will ensure the screen's magnetic closure works properly. Once the top of the screen is in place, slowly peel off the white backing tape from the two sides. Press the hook & loop tape to the frame moving from top to bottom. Make sure the screen is loose enough to ensure the magnets line up and close easily.

**Step 6:**


Make sure the screen opens and closes properly. Make adjustments if necessary. Enjoy your new Magnetic Screen Door!

 **WarehouseFull**

www.awarehousefull.com

140 Central Ave. Farmingdale, NJ 07727

888.223.3050

 **WARNING:** Cancer
and Reproductive Harm -
www.P65Warnings.ca.gov

Made in China
FEN 92500



X001QSSCAL

Magnetic Screen Door, Black...inch x 82 inch, Fenestrelle
New