

POLY FOAM TEE & ELBOW INSULATION

Pre-Slit, Self-Sealing Design

Use Tee and Elbow joints to easily insulate bends and joints.

Preparation:

Install when the temperature is between 40°- 90°F (5°-32°C).

Installation:

1. For bends and corners, place elbow insulation with slit side facing outwards.
2. For "T" connections, slide insulation from bottom, with slit side facing outwards.
3. Remove backing paper and press sides to seal.
4. Seal any remaining seams with duct tape.



AISLANTE PARA CODOS Y COYUNTURAS EN "T" DE ESPUMA DE POLIURETANO

Diseño Pre-rajado y Autosellante

Utilice coyunturas de codo y en "t" para aislar facilmente esquinas y juntas.

Preparación:

Instále cuando las temperaturas estén alrededor de 40°- 90°F (5°-32°C).

Instalación:

1. Para curvas y esquinas en la tubería, coloque la coyuntura de codo con el lado pre-hendido hacia afuera.
2. Para conexiones en "T", coloque el aislamiento por abajo, con el lado pre-hendido hacia afuera.
3. Desprenda el papel de reverso y presione los lados para sellar
4. Selle cualquier unión restante con cinta para conductos.

