

# KOHLER®

## Roughing-In

**K-T948, K-T949, K-T950, K-951, K-952**  
**STILLNESS®**  
**BATH AND SHOWER FAUCET TRIM**

### Product Information

#### Applicable product:

Bath and shower trim, blade handle	K-T948-4
Shower only trim, blade handle	K-T949-4
Valve only trim, blade handle	K-T950-4
Bath spout	K-952

#### Required accessories:

RiteTemp® valve <b>OR</b>	K-304-*
HiFlow RiteTemp valve with stops <b>OR</b>	K-2971-KS
RiteTemp valve with diverter <b>OR</b>	K-11748-K
RiteTemp valve with diverter and stops	K-11748-KS

\* For a complete listing of all the RiteTemp valves, refer to the K-304-\* Specification Sheet or Roughing-In Sheet.

#### Optional accessories:

HiFlow Rite-Temp® thin wall installation kit	88526
Deep roughing-in kit for Rite-Temp® valve (lever and cross handles)	1016154

### Installation Notes

Install this product according to the installation guide.

**NOTICE: Risk of product damage.** Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Install this product according to the installation guide

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Cap shower outlet if deck-mount spout, diverter, or handshower is connected to spout outlet.

Install straight pipe or tube drop of 7" (17.8 cm) to 18" (45.7 cm) with single elbow between valve and wall-mount spout.

