

Align kick plate position,  
drill pilot holes,  
then secure with  
screws included.

