

IMPORTANT: We recommend you perform all steps from start to finish on the back of a drawer face to get used to using the product and to identify an exact process to achieve your desired look.

WARNING: Wear a NIOSH approved respirator to control dust exposure when sanding.

SURFACE PREPARATION: Aqua Coat White Cabinet Grain filler should be applied after your cabinets have been well cleaned, deglossed, and sanded to 150. Remove dust with forced air or a damp rag (water only). Do not use tack rags as they have oils and waxes.

TINTING: Can be tinted with water soluble tints and dyes.

DIRECTIONS FOR USE: Work filler generously into open wood grain and pores with a small squeegee, bondo blade, old credit card, or fingers with a glove. Filler may also be applied with a cotton rag or a soft cloth in a circular motion. Lightly scrape off excess with squeegee, bondo blade, or an old credit card. Let dry 45-60 min. Then VERY lightly sand with 220 grit sandpaper or a fine scotchbrite sanding pad immediately before your next application of grain filler or your first coat of paint. Allow overnight dry time before final coats of paint. The only reason you are sanding is for adhesion purposes. 2-3 coats are recommended. Follow with 1-2 coats of primer and 2 coats of paint. Allow grain filler overnight dry time before final coats of primer and paint are applied.

For Application Tutorials visit www.aquacoat.com

VOC : < 100 g/ l