



Items needed for installation:

- 2 1/2" long construction screws
- Wood shims
- Level
- Phillips Tip Screwdriver
- Hole Saw
- Clear Silicone Caulk
- Cloth Towels

Before you begin please read and familiarize yourself with this installation guide. Consult professional help if needed.

Installation Guide for the Vanity Cabinet:

1. Cut openings in cabinet back to allow drain and water supply lines access into cabinet.
2. Level cabinet front to back and side to side, use shims if necessary.
3. Attach cabinet to wall with construction screws.
4. Cabinet is now ready for countertop and plumbing installation.
5. If door gap needs adjustment, even gap using Hinge Adjustment Guide.

Installation Guide Vanity Top:

6.

1. Remove cabinets from packaging and arrange together in the correct order of installation.
2. Carefully match cabinet fronts together and clamp using soft jawed clamps. Pre-drill two 1/8" holes through the inside of one cabinet and insert 1-1/4" screws through the holes securing the cabinets together. Mount cabinets to wall and install Stretcher as in Step 1 and Step 2 above.

a spot of clear silicone adhesive on each corner of stretcher top. Carefully set Marble Vanity Top into place making sure Vanity Top is centered left to right and flush with back of stretcher.

If you have any trouble during the installation of your D'Vontz cabinet, please call our Customer Service department at 877-322-3600.

Thank You for choosing D'Vontz.

Please install this product according to the installation guide and all local plumbing codes.