

Align pull plate position,
drill pilot holes, then secure
with 8 screws included.

