

NO-DIG[®]

LANDSCAPE EDGING[®]

INSTALLATION INSTRUCTIONS

Always use proper safety precautions when cutting and spiking edging. Protective eyewear and gloves are recommended during installation.

1



Clear the installation area of grass, loose soil, and debris. Slide edging pieces together so anchoring tabs overlap.

2



Hammer spikes through tabs at the ends of the installation and connection points. Additional spikes are available separately.

3



Backfill with mulch, river rock, or other ground cover. Assure tabs are completely covered with a thick layer of bedding material.

CONNECTION SYSTEM



Overlapping post system stabilizes and strengthens joints.

Interlocking anchoring tabs eliminate separate connection pieces.



Seamless connection creates uninterrupted borders.

HELPFUL TIPS & INFORMATION

Installation:

Enough anchoring spikes are included to accommodate a typical installation. Certain conditions and landscape designs can require additional spikes, which are available in stores and online.

Anchoring spikes should be hammered only to the top of the edging tab. Hammering the spike to the point the tab bends can damage the edging.

Generously cover tabs with soil and groundcover. Heavy bedding materials such as rock and mulch, tend to perform best.

Site Preparation:

Soil must be solid and level. Assure there is no debris between the edging tab and the dirt below. Compact the cleared soil prior to installation to reduce spike movement from shifting ground and frost heave.

Weed fabric can minimize the spread of invasive weeds and grass. Install fabric according to product directions, then place the landscape edging over the fabric and hammer spikes through the tabs and fabric.

