ASSEMBLY INSTRUCTIONS



A Tripod

Iron Hook

INSTALLATION STEP 1

STEP 3

CAUTION

STEP 8

Black wire

from the

White wire

from the

Install iron hook into the a tripod with the hex nuts C then embed the component in the ground level with concrete. Note: the threaded nipple must protrude outward 1 5/8"(41 mm).

1 5/8" (41mm) \frown

STEP 2

Successively install the decorative component into centre pillar and secure them with washer A and hex nuts A.

