## Assembly instruction (See Video first, it will save you One hour)



| 1: M6.3 x 50mm | 2: M6.3 x 80mm   | 3: M6.3 x 30mm | 4: M6 x 50mm |
|----------------|------------------|----------------|--------------|
|                |                  | O              |              |
| 4 PCS          | 2 PCS            | 4 PCS          | 2 PCS        |
| 5: M6 x 60mm   | 6: M6 NUT        | 7: M6 WASHER   | 8: M6 x 32mm |
| O Management   | 6                | Ô              |              |
| 4 PCS          | 6 PCS            | 6 PCS          | 1 PC         |
| 9: WRENCH      | 10: ALLAN WRENCH |                |              |
| S==C           |                  |                |              |
| 1 PC           | 1 PC             |                |              |

NOTE: UNIT SHOULD BE ASSEMBLED BY TWO OR MORE PEOPLE. DO NOT TIGHTEN ANY BOLTS UNTIL ALL BOLTS HAVE BEEN STARTED!





