

PLASTIC AREA WELL

INSTALLATION INSTRUCTIONS

INSTALL NOTES

Mount to all with holes 40" center to center

Window well should be installed approximately 3" below the bottom of the window opening in the foundation wall.

The top of the window well should extend approximately 2" above grade.

Mounting
Hole



INSTALLATION

1. Mark the location of the top mounting holes on the foundation. *NOTE: The location of the mounting holes should be 40" from center to center.*
2. Drill two hole on the markings and remove all concrete dust from the holes before proceeding.
3. Attach window well using masonry nails, anchors, or other fasteners.
4. Using the remaining holes on the window well flange, drill the remaining holes.
5. Place remaining hardware into the holes, add 1" flat washers and nuts and tighten into place.
6. Backfill 1" around the outside of the window well.

