


[illegible]

Turn off electricity at street breaker or main line box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the Batem. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect Batem from power source before replacing bulb. Make sure bulb is given sufficient time to cool before removal.

Step 1
A small bulb into inside and screw snug into place

PART	DESCRIPTION	QUANTITY
MS	WRENCH	2000
CS	Cable Box Assembly	2000

A. The lamp body is fixed and locked in the upper cover with screws.



The diagram shows a three-phase motor control circuit. It includes a three-phase power supply (380V) connected to a three-phase switch (QF) and a three-phase motor (M). The motor is protected by a thermal relay (JR) and a thermal protector (PT). The thermal protector is connected to the motor's winding and provides a signal to the thermal relay, which then controls the three-phase switch to stop the motor if an overload is detected.

⚠️ WARNINGS AND CAUTIONS AVERTISSEMENTS ET MISES EN GARDE ADVERTENCIAS Y PRECAUCIONES
ÉTENDRE L'ÉLECTRICITÉ au coffret à fusibles principal (ou au disjoncteur) avant de commencer l'installation en étiquetant le disjoncteur ou en aménageant un fusible.

- VOIR UN ELECTRICIEN QUALIFIE POUR GARANTIR UN CONDUCTEUR DE PROTECTION D'ISOLEMENT CORRECT.**
 En cas de doute sur l'installation électrique, voir un électricien licencié.
DESCONNECTER LA ELECTRICIDAD en la caja de interruptor de seguridad apagando el interruptor de circuitos o retirando el fusible.

- CONSULTE A UN ELECTRICISTA CALIFICADO PARA ASEGURAR EL CONDUCTOR DE CIRCUITO DE RENDIDO ADECUADO. SI TIENE DUDA SOBRE LA INSTALACIÓN ELÉCTRICA, CONSULTE A UN ELECTRICISTA CERTIFICADO.**

1. Fix the support (B) onto the mounting (A) with the nut (D) on the mounting (A).
2. Attach mounting (B) to junction box using outlet box screws (E).
3. Connect the wires to the mounting (A) as in the case of the outlet box using the terminals of the mounting (E).
4. Fix the band of the support (A) to the box (B) with the bolt (C) different to the bolt (D).

- de la boîte de sortie (E).

3. Strip 1/2 in. of insulation from wire ends. Twist stripped ends together with pliers slack to black, power and white to white (neutral). Attach copper wire ground wire.
4. Attach wire nut(s). Tape (insist) and wires together with electrical tape.

4. Attacher les capteurs de connexion (D). Attacher les capteurs (D) et les fils ensemble avec du ruban isolant.

- 3. Pagar la com del alojamiento**
4. Colocar las empresas místicas (D). Escribir las empresas (U) y las salidas juntas con un signo igual.

5. Attach the fixture to the ceiling by aligning the angle iron protrudes from the mounting string to the hole in the ceiling platelet. *Warning:* the angle iron protrudes from the ceiling platelet.

- prevent workers from slipping onto the protruding nipple until the fixture is held firmly to the ceiling.

