

LED TOW LIGHT

Bluetooth Pairing Process



1. Plug the new transmitter into the receptacle.

2. The battery indicator should have at least two bars or more



3. Bring the lights with you to the driver seat.

4. Press the on/off button 4 times, and hold until the indicator bar starts to flash.



5. Test out all 3 functions of the turn/tail/stop hazard warning flashers before use.