



LANDSCAPE WALL | KEYSTONE COUNTRY MANOR®



INSTALLATION INSTRUCTIONS



Mark & Dig

Mark an outline of your project. Then dig a shallow trench 12" (305mm) deep by 20" (508mm) wide.



Base & Tamp

Add 6" (152mm) of granular base material. Compact base to avoid settling.



Level

When burying the first course of units, it is very important to level them front-to-back and side-to-side.






Pin & Stack

Insert pins in desired hole location for setback or vertical wall options. Place next course of units centered over units below.



Cap

Finish the wall with a cap unit to give it a polished look. Secure in place with concrete adhesive.

Retaining Wall Height	Retaining Wall Length (measured at wall face including curves)				
	10' (3.0m)	25' (7.6m)	35' (10.7m)	75' (22.9m)	100' (30.5m)
Large and small unit combination (front to back) 					
12" (305mm) - 2 courses	12 (each)	30 (each)	42 (each)	90 (each)	120 (each)
24" (610mm) - 4 courses	24 (each)	60 (each)	84 (each)	180 (each)	240 (each)
30" (762mm) - 5 courses	30 (each)	75 (each)	105 (each)	225 (each)	300 (each)
Large units only (front to back) 					
12" (305mm) - 2 courses	16	40	56	120	160
24" (610mm) - 4 courses	32	80	112	240	320
30" (762mm) - 5 courses	40	100	140	300	400
Capping course (front to back): Optional use as a wall up to 18" 					
3" (76mm) - 1 course	11	28	39	82	110
6" (152mm) - 2 courses	22	55	77	164	219
12" (305mm) - 4 courses	44	110	153	328	436
18" (457mm) - 6 courses	66	164	230	491	655



Keystone Retaining Wall Systems LLC • A Contech Company
4444 West 78th Street • Minneapolis, MN 55435
(952) 897-1040 • www.keystonewalls.com

©2017 Keystone Retaining Wall Systems LLC

