

Installation Steps

Easy-to-follow instructions enclosed.

1. Position in desired location and mark screw holes (fig. A).
2. Drill 7/32-in pilot holes.
3. Use anchors for hollow wall applications.
4. Install and tighten screws (fig. B).

