

# Spira SPA-B001 Mailbox Bracket

A Brand of 603 Products, LLC

## Assembly Instructions

### Spira SPA-B001 Mailbox Bracket

Kit includes:

- SPA-B001 Mailbox Bracket

Fasteners

Mailbox to Post (2) Stainless Steel Lag Bolts (2) Stainless Steel Washers

1. Identify height of mailbox shelf to be 41" - 45" above the road surface. Mark and drill the top and bottom holes of the bracket with 1/4" holes as deep as the length of the lag bolts provided.

2.

Install 3/8" lag bolts and washers into mailbox post as shown. Tighten nuts with 9/16" wrench or socket.

Lag Bolt and Washer (x2)

Bracket

### Installation

Install Mail Shelf 41"-45" above road surface

41"-45"

S04

