
Drilling Template

1. Tape paper template on wall where suggestion box will be mounted.
(Use carpenter's level along the dashed line to make sure its leveled)
2. Drill through template for plastic anchors.

