

LANDSCAPE WALL | KEYSTONE GARDEN WALL®

Garden Wall

INSTALLATION INSTRUCTIONS



Start by digging a shallow trench 4"(102mm) deep by 12" (305mm) wide. Cut through and remove any sod, roots or large rocks. For organic loam soils, dig 4" (102mm) deeper and add a leveling pad of sand or gravel. Compact and level the soil to receive the first course of Keystone Garden Wall.

Place and level the first Keystone Garden Wall unit. Level each

additional unit on the base course

outside edges touch. If your wall contains both straight and curved

Starting with straight areas first,

the second course.

areas, start with a straight area and build into the curves. Complete the base course before proceeding to

as you place it, making sure that the

1. Prepare Wall Location



2. Place & Compact Backfill



3. Install Additional Courses

Remove Edges

To remove outside lugs or edges of retaining lip, hold unit securely or place at angle on ground. Strike the lug firmly with a hammer. Always wear safety glasses to protect eyes from chips.





Building Curves

Curves as small as 2'-2" (660mm) in radius can be built with Keystone Garden Wall. Convex & concave course bonding will adjust sideways. If stack bond occurs, remove rear interlock lip as shown or cut units accordingly to get back to running bond.





Typical Garden Wall Section

Use clean granular backfill such as gravel or crushed stone for drainage and to prevent soil from leaching through the wall. A commercial filter fabric (stocked by most garden supply stores) may be used when existing site soils are used for backfill.

.....

Keystone Retaining Wall Systems LLC • A Contech Company 4444 West 78th Street • Minneapolis, MN 55435 (952) 897-1040 • www.keystonewalls.com

f 🎔 🖸 🖗 🖸 🛱



©2017 Keystone Retaining Wall Systems LLC