



882

Soft Close Pocket Frame Hardware

Installation Instructions




Components list




Pre-installation

TOOLS REQUIRED




HARDWARE INCLUDED





PREPARE THE ROUGH OPENING


Height of Rough Opening (Table 1)			
Nominal Door Height	Minimum Height of Rough Opening	Bracket Fastener Height from finished floor	Bracket Fastener Height from sub-floor
80"	84-1/2"	80-3/4"	81-1/2"
84"	88-1/2"	84-3/4"	85-1/2"
96"	100-1/2"	96-3/4"	97-1/2"
108"	112-1/2"	108-3/4"	109-1/2"
Custom	Door Height + 4-1/2"	Door Height +3/4"	Door Height +1-1/2"


Width of Rough Opening (Table 2)		
Nominal Door Width	Width of Rough Opening	
24"	49"	
26"	53"	
28"	57"	
30"	61"	
32"	65"	
34"	69"	
36"	73"	
Custom	(2 X Door Width) + 1"	
































Cutting Instructions





Turn the header on side and cut the nailing boards to marked length. Make sure not to cut the track or the wood header.



6 Turn header and cut the other side.

Cutting header for Non-standard door width:

- 1. Measure door width and multiply by 2, then add 1"(25mm).
- 2. Mark header and cut following step 2. Then cut track following step 3.
 - 3. Measure door width and add 7/8"(22mm).
 - 4. Mark header nailing boards and cut following step 5 & 6.



Copyright © 2024 ASSA ABLOY Americas Residential Inc. NATIONAL, the National logo, the National Hardware logo are trademarks of ASSA ABLOY Americas Residential Inc. Made in China (TY) | www.national - hardware.com | (800) 346-9445

