

Installation Steps

Easy-to-follow instructions enclosed.

1. Use template to determine location for mounting holes. Use level vertically to ensure holes are level.
2. Mark holes and drill 13/64-in diameter holes. Ensure drill is kept level.
3. Insert screws through washers and door to attach door knocker as shown in photo.
4. If screws are too long, they can be sawed to the appropriate length.
5. For doors greater than 1-3/4-inches, use #10-24 machine screws (not included).

