

STANCHION ASSEMBLY

Easy to set up, remove and store. They are economical, strong, durable, weather and fade resistant and will never rust.

ASSEMBLY INSTRUCTIONS

1. Set base of unit on flat surface. For added stability, the base can be filled with sand or gravel through the opening in the top of the base. Fill approximately 3/4 of the way full.

CAUTION: NEVER FILL BEYOND STEM OF BASE.

2. Push pole firmly down onto base until it stops at base of stem.
3. Insert the C-hook into the slots on the top of the pole.
4. Determine the distance between each stanchion. Using wire cutters, cut your available plastic chain to the desired length, allowing approximately 6" for the drape of the chain.

Ball Top:

5. Put the ball top into the pole and twist to lock it into place. Your stanchion is now completely assembled.

**CAUTION:
IF STANCHION IS TO BE LIFTED,
MOVED OR STORED, DISASSEMBLE
AND EMPTY BASE.**