

Align towel hook position, drill pilot holes,
then secure with 2 screws included.

