Wall-Hung Basins



INSTALLATION INSTRUCTIONS

Tools Needed

• Screwdriver • Drill & Bits • Level • • Plumbers Basin Wrench to secure Faucet (Optional) • Wrench • Pencil • Tape Measure • Plumbers Putty •

Be sure to re-inforce wall before installation. We recommend a 2"x12" securely fastened to wall study at the desired height for your installation.



Wall Hung Installation



- 1. Determine the height you want. Place basin against the wall. Use a level to make sure both sides are level. Mark location on wall for mounting holes on back of sink.
- 2. Position each metal mounting bracket against the underside rear of basin and against the wall. Mark the location of mounting bracket holes on the wall.
- 3. Remove the basin from the wall. Wall should be reinforced before continuing.
- **4.** Start to drill hole in **2**"**x12**" **re-inforced wall** for mounting hardware. Screw large wood screws provided into wall.
- **5.** Before replacing basin, it would be convenient at this point to mount the faucet according to the manufacturer's instructions.
- **6.** Slide sink onto bolts and ensure that it is level. Slide plastic flange washers and metal washers onto bolts. Thread hex nuts on snugly.
- **7.** Hold basin on wall brackets and ensure that it is level. Secure sink to wall using bolts through holes in back of sink.
- **8.** Connect all supply tubes to the faucet. Connect trap and drain assembly as described by the manufacturer.

NOTE: Determine whether your installation requires **Hangers** (pair) or a **Bracket** (one). These can be purchased separately to provide added support.





DO NOT over tighten or you may damage basin.

Bracket Hangers