LED WallScone

WS17014 INSTALLATION SHEET

START FROM HERE

- Make sure POWER is COMPLETELY OFF at the fuse box
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area
- Wear gloves at all time during this installation
- Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

- Remove the fixture from its original packaging. Remove the mounting crossbar (1c) from the canopy (2b) by unthreading two screws (2a). Attach the mounting crossbar (1c) to the electrical junction box (1a), by using screws (1d) provided in the hardware package.
- Attach the canopy to the mounting plate. First connect all wires correctly G ground to ground, N neutral wire (white to white), L live wire (black to black) with provided marrettes (1b) from the hardware package. Now place the canopy (2b) onto the mounting crossbar (1c). As you move the canopy, align the side holes to the holes on the mounting crossbar (1c), and secure the canopy by two screws (2a).
- **3** You have now completed the installation of your fixture, enjoy.

Please Note:

- All Kuzco LED fixtures come with pre-wired LED module(s).
- Unless instructed to do so, please do not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage.
- For dimming, an ELV (Electronic Low Voltage) type of dimmer is required.



19054 28th Avenue Surrey, BC Canada V3Z 6M3 T: 604 538 7162 TF: 1-855 85 KUZCO F: 604 538 7196 W: kuzcolighting.com 20181127